

Electric — Frame number is ID

1980	G1-E	J14 000101	1991	G9-EG	JG6 000001
1981	G1-E2	J14 100101	1992	G9-EH1	JG6 100101
1982	G1-E3	J22 000101	1992	G9-EH2	JH& 000125
1983	G1-EM3	J26 000101	1993	G9-EJ	JH7 100101
1984	G1-EM4	J36 000101	1994	G9-EK/K1	JH7 200149
1985	G1-EM5	J36 010101	1994	G9-EKP	JH7 201801
1986	G1-EM	J36 011201	1995	G9-EM	JH7 300101
1985	G2-E5	J41 000101	1995	G14-Ultima	JN3 000101
1986	G2-E	J41 016101	1995	G14-EM	JN4 100101
1987	G2-EB	J41 030101	1996	G14-EP	JN4 200101
1988	G2-EB	J41 053101			
1988	G2-EC	JE2 000001	1996	G16-EP	JN8 000101
1989	G2-ED	J56 000101	1997	G16-ER	JN8 100101
1990	G2-EF	J56 100101	1998	G16-ES	JN8 200101
1991	G2-EG	J56 200101	1999	G16-ET	JN8 300001
2000	G16-E	JN8 400101			
1987	G3-E	J46 000101	2001	G16-E	JN8 500101
2002	G16-E	JN8 600101			
1990	G5-EF	J51 000101			
1991	G5-EG	J51 100101	1996	G19-EP	JR1 000101
1992	G5-EH	J51 200101	1997	G19-ER	JR1 100101
1998	G19-E	JR1 200101			
1990	G8-EF	JF3 000001	1999	G19-E	JR1 300101
1991	G8-EG	Jf3 100101	2000	G19-E	JR1 400101
1992	G8-EH	JF3 200101	2001	G19-E	JR1 500101
1993	G8-EJ	JF3 300101	2002	G19-E	JR1 600101
1994	G8-EK/K1	Jf3 400101			
1994	G8-EKP	JF3 401801			
1995	G8	JF3 402000			

G1 serial # is under rear bumper on frame cross member.

G2 serial # is found under bumper on early models, & from 1988 under the seat.

G9 serial # is found under the seat.

G14, G16, G19 & G20 is just under glove box on left driver's side.

